

METREL DELTAPAT GT PAT TESTING KIT



The **Metrel DeltaPat** PAT Testing kit is a quality all in one system for testing appliances, extension cords, tools, etc to Australian standards without complexity or even the need to find an AC source to power the units.

The kit contains the following:

- METREL DELTAPAT GT PAT Tester configured to Aust, standards complete with Test Lead Set and Clips, NiMH Batteries and Charger, PAT Link Pro Software and USB Cable, Manual & Calibration Certificate, Manual on CD
- TLP-2824 Thermal Label Printer and NiMH 4.5AHr Battery Pack, Charger
- 2 x Bluetooth Dongles and Printer Adaptor Cable
- Android Pat Link App & Authorisation Code to operate complete system from Android device
- Hard Pelican style carry case with custom cut out's for the system

This complete system enables all your testing to be done on site with no external power and printing test tags even with your company logo using the Bluetooth dongles for communication.

The Android App enables the system to be operated by an Android device such as a Tablet or Phone allowing the Deltapat to perform the tests, save the test to the Android device and then send to the printer for the Tag to be produced. For re-testing the camera on the device can be used to scan the tag to recall the asset ID and the test required. All data can be stored in the Deltapat (up to 1500 tests) for download to PAT Link software on a PC for archiving and reports. Please view the Deltapat spec under "Appliance Testers".

The Deltapat will perform the following tests:

- Earth Continuity - Insulation Resistance @ 250/500V - RCD Tests @ 10/15/30ma
- Differential leakage current - Touch leakage current - Substitute leakage current
- TRMS Voltage measurement - Power measurement

UNITEST INSTRUMENTS - U4/9 Vale St, MALAGA WA 6090

PH: (08)9248 8601 FX: (08)9248 8602 Email: unitest@optusnet.com.au

WWW.unitestinstruments.com.au