

# Independent Earth Leads

## Heli-T Trailing Earths PTE-010 & PTE-015

It is no longer acceptable to use water pipes and metal structures as a reliable independent earth. Independent earths are required for many applications including:

- Polarity testing on new services
- Testing neutral integrity
- Earthing of de-energised equipment during repair or maintenance
- Investigations of electric shock
- Earthing of water services when changing meters

### Designed & manufactured for ease of use and long life:

- All stainless steel for strength and corrosion resistance
- T-handle for ease of insertion
- Unique helical stake screws itself into the ground and maximises contact with the soil
- 25m of double insulated 130 strand 6 Amp super-flexible cable resists kinking and winds up easily
- PBT engineered polymer reel resists breakage
- Brass slip-ring with stainless steel spring contact ensures reliable contact between cable and earth
- Adjustable tension to prevent reel "over-run" and to compensate for wear over time
- Supplied with male safety banana plug (PTE-015) and removable elephant clip for connection to test instruments or metal structures
- Optional female connector version (PTE-010)
- Fully repairable in case of accidental damage

